

AN X-RAY TRANSMISSION GRATING SPECTROMETER FOR LYNX

Hans M. Günther, Ralf Heilmann

SPIE 10699-39 (2017)

MOTIVATION


- Plenty of X-ray observations require high-res spectroscopy, e.g.
 - temperature and density sensitive line ratios
 - narrow line WHIM absorption
 - resolve kinematic profile of wind emission lines
 - ...
- Microcalorimeters are good at high energies
- Grating spectroscopy is better at low energies
- Lynx PSF + advanced gratings: > 10 times Chandra resolution
- Lynx mirror + advanced gratings: up to 1000 times Chandra area at O VII

SIMULATION INPUT

- MARXS ray-trace code (Günther et al, ApJ, 2017):
 - Freely available at <https://github.com/Chandra-MARX/marxs/>
 - Hundreds of unit tests
 - Tested against lab data and Chandra observations
 - Written in Python
- Data:
 - Mirror PSF: Assuming 0.5 arcsec half-power diameter
 - Critical angle transmission gratings (CAT), etched from Si. Using predicted efficiencies for 5.7 micron deep gratings.
 - Various filter curves, CCD QEs etc.


SIZE OF GRATING FACETS

- Small grating facets follow the Rowland torus well, but more area is lost for mounting structures, also number goes up.
- Large gratings use the space better, but diverge from the ideal form more.





CAN WE HAVE OUR CAKE AND EAT IT, TOO?

THE SIMPLE APPROACH: RECTANGULAR GRATINGS



CAN WE HAVE OUR CAKE AND EAT IT, TOO?

PRESERVING THE BLAZE: BEND GRATINGS




CAN WE HAVE OUR CAKE AND EAT IT, TOO?



RECOVERING THE RESOLUTION: CHIRPED GRATINGS

- projection lithography masks can be written in any pattern
- CAT grating production process with projection lithography is used for ARCUS
- talk to Ralf Heilmann


TRADE OFF RESOLVING POWER AND EFFECTIVE AREA





CAN WE HAVE OUR CAKE AND EAT IT, TOO?




CCD PLACEMENT



EFFECTIVE AREA AND RESOLVING POWER



HIGH-ENERGY PHOTONS PASS RIGHT THROUGH



SUMMARY

- CAT gratings can deliver the R, Aeff required by the Lynx science with (mostly) today's technology
- Alignment tolerances are very forgiving
- Trades and options:
 - Chirped gratings
 - Two traces
 - Grating coating